Figure-1

BLACK
ground — 1

YELLOW / RED
to blower — 10

BLOWER SWITCH

WHITE
to starter — 8

PUSH START

RED/WHITE
to oil switch and alt EXC — 7

PURPLE
to glow plug solenoid — 5

RED
from battery — 2

KEY SWITCH

S

B

I

10A CIRCUIT BREAKER

low oil light

+ alarm
P   C

high temp light

VOLT
G
L

LIGHT BLUE
to oil switch — 11

TAN
to temp switch — 12

FUEL
G
I
S   L

PINK
to fuel tank — 6

TEMP
G
I
S   L

YELLOW
to temp sender — 3

TACH
G
I
S   L

BROWN
from stator — 4